

### **Supra Lite Transmitter**

1. All Supra Lite Transmitters come with a motion sensor. When the dog stops for more than 4 seconds, the “beep” will double indicating the dog is on “point” for bird dogs, or treed for squirrel dogs.
2. To turn the transmitter on, place the positive end (smooth end faces out) of the battery in the battery compartment first.
3. Use a quarter, or other coin to tighten the end cap down. Check to make sure the rubber seal is in place to ensure the transmitter is watertight. Also check for brass spring in the end cap before tightening.
4. If the transmitter appears to have gotten wet during the hunt, use a hair dryer on lowest possible setting to dry.
5. Completely remove battery after use.
6. Transmitter uses 3.0V Lithium Battery.



**Meets AFTCA standards for their events-----AKC approved for bird dog field trials-----Weight 4.5 ounces**